



What is changing?

The Oil Furnace Heat Exchanger Clean-Outs will now be accessible through a tube that protrudes through the inner front of the furnace. The tube will have a gasket and cap secured by two screws.

What Models are changing?

LHO 145, LHO 190, LHO 225


Why are the Clean-Outs changing?

In response to numerous customer requests the new design will allow direct access to the heat exchanger from the inner-front. The new design will eliminate clean-out covers and tools falling between the inner-front and the heat exchanger.

Clean-Out Tubes

Cap with Screws

Gasket





Clean-Out Tubes and Caps
through the Inner-Front

Can I order Replacement Caps and Gaskets?

Yes use part number:
550001642 – Kit, Clean out cap and gasket (2 per)

How do I order a Replacement Heat Exchanger for an existing furnace?

Order all replacement heat exchangers using the part numbers listed below. The heat exchanger kit is shipped complete with all the parts required to convert the furnace to the new style.

Service Replacement	
Part Number	Description
550001630	KIT,H.E. REPLACEMENT LHO 145
550001632	KIT,H.E. REPLACEMENT LHO 190/225

I have additional questions?

Please feel free to contact the technical service staff at 800-325-5479.

Availability

Production of the new heat exchanger design began on December 11, 2006. As our current inventory is depleted, the new heat exchangers will arrive in the field.